

Category B+E Safety Questions 01/07/2008				
Question	Topic	Show / Tell	Question	Answer
BE1	Brake Fluid	Show	Open the bonnet, identify where the brake fluid reservoir is and tell me how you would check that you have a safe level of hydraulic brake fluid.	Identify reservoir, check level against high/low markings.
BE2	Indicators	Show	Show me how you would check that the direction indicators are working.	Applying the indicators or hazard warning switch and checking functioning of all indicators.
BE3	Loading	Tell	Tell me the main safety factors involved in loading this vehicle.	The load should be distributed evenly throughout the trailer. Heavy items should be loaded as low as possible so that they are mainly over the axle(s). Bulkier, lighter items should be distributed to give a suitable 'nose weight' at the towing coupling. The nose weight should never exceed the vehicle manufacturer's specifications.
BE4	Loading	Tell	Tell me the main safety factors involved in securing a load on this vehicle	Any load must be carried so that it does not endanger other road users. It must be securely stowed within the size and weight limits for the vehicle. The load needs to be secure so that it cannot move or fall from the vehicle when cornering or braking.
BE5	Doors	Show	Show me how you would check that your vehicle & trailer doors are secure	Physical checks should be made to ensure that windows, roof light and all doors, including cargo doors, are properly closed.
BE6	Tyres	Tell	Tell me how you would check the tyres to ensure that they have sufficient tread depth and that their general condition is safe to use on the road.	No cuts and bulges, 1.6mm of tread depth across the central $\frac{3}{4}$ of the breadth of the tyre and around the entire outer circumference.
BE7	Horn	Show	Show me how you would check that the horn is working (off road only).	Check is carried out by using control (turn on ignition if necessary).
BE8	Engine coolant	Show	Open the bonnet, identify where you would check the engine coolant level and tell me how you would check that the engine has the correct level.	Identify high/low level markings on header tank where fitted or radiator filler cap, and describe how to top up to correct level.

Category B+E Safety Questions 01/07/2008				
Question	Topic	Show / Tell	Question	Answer
BE9	Handbrake	Show	Show me how you would check the parking brake for excessive wear.	Demonstrate by applying parking brake that when it is fully applied it secures itself, and is not at the end of the working travel.
BE10	Windscreen Washers	Show	Show me how you would clean the windscreen using the windscreen washer and wipers.	Operate control to wash and wipe windscreen (turn ignition on if necessary).
BE11	Windscreen Demister	Show	Show me how you would set the demister controls to clear all the windows effectively, this should include both front and rear screens.	Set all relevant controls including; fan, temperature, air direction / source and heated screen to clear windscreen and windows. Engine does not have to be started for this demonstration
BE12	Rear fog light	Show	Show me how you would switch on the rear fog light(s) and explain when you would use it/them. (No need to exit vehicle)	Operate switch (turn on dipped headlights and ignition if necessary). Check warning light is on. Explain use.
BE13	Headlights	Show	Show me how you switch your headlight from dipped to main beam and explain how you would know the main beam is on whilst inside the car	Operate switch (with ignition or engine on if necessary), check with main beam warning light.
BE14	Brake lights	Show	Show me how you would check that the brake lights are working on this vehicle. (I can assist you, if you need to switch the ignition on, please don't start the engine).	Operate brake pedal, make use of reflections in windows, garage doors, etc, or ask someone to help.
BE15	Head Restraints	Tell	Tell me how you make sure your head restraint is correctly adjusted so it provides the best protection in the event of a crash.	The head restraint should be adjusted so the rigid part of the head restraint is at least as high as the eye or top of the ears, and as close to the back of the head as is comfortable. N.B. Some restraints might not be adjustable.